

Anschlußnummern der Taster an den Block- (05) und Hilfsblockkarten (06)

GP 05	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	4 3 2 1	8 7 6 5	12 11 10 9	16 15 14 13	20 19 18 17	24 23 22 21	28 27 26 25	32 31 30 29	36 35 34 33	40 39 38 37	44 43 42 41	48 47 46 45	52 51 50 49	56 55 54 53	60 59 58 57	64 63 62 61
	68 67 66 65	72 71 70 69	76 75 74 73	80 79 78 77	84 83 82 81	88 87 86 85	92 91 90 89	96 95 94 93	100 99 98 97	104 103 102 101	108 107 106 105	112 111 110 109	116 115 114 113	120 119 118 117	124 123 122 121	128 127 126 125
	132 131 130 129	136 135 134 133	140 139 138 137	144 143 142 141	148 147 146 145	152 151 150 149	156 155 154 153	160 159 158 157	164 163 162 161	168 167 166 165	172 171 170 169	176 175 174 173	180 179 178 177	184 183 182 181	188 187 186 185	192 191 190 189
	196 195 194 193	200 199 198 197	204 203 202 201	208 207 206 205	212 211 210 209	216 215 214 213	220 219 218 217	224 223 222 221	228 227 226 225	232 231 230 229	236 235 234 233	240 239 238 237	244 243 242 241	248 247 246 245	252 251 250 249	256 255 254 253

GP 06	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	260 259 258 257	264 263 262 261	268 267 266 265	272 271 270 269	276 275 274 273	280 279 278 277	284 283 282 281	288 287 286 285	292 291 290 289	296 295 294 293	300 299 298 297	304 303 302 301	308 307 306 305	312 311 310 309	316 315 314 313	320 319 318 317
	324 323 322 321	328 327 326 325	332 331 330 329	336 335 334 333	340 339 338 337	344 343 342 341	348 347 346 345	352 351 350 349	356 355 354 353	360 359 358 357	364 363 362 361	368 367 366 365	372 371 370 369	376 375 374 373	380 379 378 377	384 383 382 381
	388 387 386 385	392 391 390 389	396 395 394 393	400 399 398 397	404 403 402 401	408 407 406 405	412 411 410 409	416 415 414 413	420 419 418 417	424 423 422 421	428 427 426 425	432 431 430 429	436 435 434 433	440 439 438 437	444 443 442 441	448 447 446 445
	452 451 450 449	456 455 454 453	460 459 458 457	464 463 462 461	468 467 466 465	472 471 470 469	476 475 474 473	480 479 478 477	484 483 482 481	488 487 486 485	492 491 490 489	496 495 494 493	500 499 498 497	504 503 502 501	508 507 506 505	512 511 510 509